

Electrical Troubleshooting

Troubleshooting Procedures



Except KB other

When the A/T control unit senses an abnormality in the input or output systems, the **[S]** indicator light in the gauge assembly will blink. However, when the Service Check Connector (located to the lower right (LHD) or left (RHD) of the glove compartment) is shorted with a jumper wire, the **[S]** indicator light will also blink the problem code when the ignition switch is turned on.

When the **[S]** indicator light has been reported on, connect the two terminals of the Service Check Connector together with a jumper wire. Then turn on the ignition switch and observe either the **[S]** indicator light.


LHD:

RHD:






Problem codes 1 through 9 are indicated by individual short blinks, Problem codes 10 through 15 are indicated by a series of long and short blinks. One long blink equals 10 short blinks. Add the long and short blinks together to determine the problem code. After determining the problem code, refer to the electrical system Symptom-to-Component Chart.



Some PGM-FI problems will also make the **S** indicator light come on. After repairing the PGM-FI system, disconnect the Back Up fuse (7.5 A) in the under-hood relay box for more than 10 seconds to reset the A/T control unit memory.

NOTE: Disconnecting the Back up fuse also cancels the radio preset stations and the clock setting. Make note of the radio presets before removing the fuse so you can reset them.



Terminal Locations

NOTE:

- Only the A and D sections of the ECU test harness are used for A/T troubleshooting.
- Unless otherwise noted, use only the Digital Multimeter for testing.


Electrical Troubleshooting

Troubleshooting Procedures


KB other

When the A/T control unit senses an abnormality in the input or output systems, the **D4** indicator light in the gauge assembly will blink. However, when the Service Check Connector (located to the lower right of the glove compartment) is connected with a jumper wire, the **D4** indicator light will blink the problem code when the ignition switch is turned on.

When the **D4** indicator light has been reported on, connect the two terminals of the Service Check Connector together with a jumper wire. Then turn on the ignition switch and observe either the **D4** indicator light.





Problem codes 1 through 9 are indicated by individual short blinks, Problem codes 10 through 15 are indicated by a series of long and short blinks. One long blink equals 10 short blinks. Add the long and short blinks together to determine the problem code. After determining the problem code, refer to the electrical system Symptom-to-Component Chart on page 14-36.



Some PGM-FI problems will also make the **D4** indicator light come on. After repairing the PGM-FI system, disconnect the Back Up fuse (7.5 A) in the under-hood fuse/relay box for more than 10 seconds to reset the A/T control unit memory.

NOTE: Disconnecting the Back up fuse also cancels the radio preset stations and the clock setting. Make note of the radio presets before removing the fuse so you can reset them.



Terminal Locations

NOTE:

- Only the A and D sections of the ECU test harness are used for A/T troubleshooting.
- Unless otherwise noted, use only the Digital Multimeter for testing.